

Tampa Bay Soaring Society
TWIN – ASTIR
Registration # N37WW
Factory Serial # 3092

Preflight Inspection

Cockpit

- Open canopy
- Check the 4 wing fasteners inside the fuselage to ensure they are locked
- Visually check all controls inside the cockpit
- Check for foreign bodies
- Check for ballast
- Test controls for full and free movement
- Check tire pressure 35.6 - 39.8 PSI
- Check condition of both tow hooks
- Check functioning of releases and wheel brake

Right Wing

- Check top and bottom of wing for damage
- Check ailerons for condition, freedom of movement and play
- Check airbrakes for condition, locking and fit

Fuselage and Tail

- Check fuselage for damage especially on the underside
- Check tail unit for correct assembly and that safety lock is in position
- Check condition of tail wheel
- Check the pitot tube, total energy venture and static vents are clean

Left Wing

- Check top and bottom of wing for damage
- Check ailerons for condition, freedom of movement and play
- Check airbrakes for condition locking and fit

Right Side of Cockpit

- Check static events